




# COMPONENT CHECKLIST

A1	A2	A3	A4	A5	A6	A7
M5X15	M6X15	M8X25	Ø16XØ6.2X1.5	M8X45	Ø16XØ8.2X1.5	Ø13XØ8.2X13
						
X4	X4	X4	X4	X4	X4	X4





X2

B1	B2	B3
	M8X10 	5mm 
X8	X8	X1

X1

					M5 
X2	X2	X3	X4	X4	X4
AA	BB	CC	DD	EE	FF


# INSTALLATION INSTRUCTION




5 Cut according to column size




6




7




**!** When installing the connector, the surface of the connector should be close to the surface of the column



8





9




10



Height adjust






Anti shedding






Tilt 0°



Tilt 5°



Tilt 10°



Tilt 15°

